

Versatile Versa Loc™ Handles



The Versa Loc™ Handles allow you to use your cookware in the oven to bake or roast. You can also finish casseroles, skillet meals, top crusts, brown the skin on poultry, toast a crumb topping, or melting cheese by placing them under the broiler for a few minutes. Simply remove the Versa Loc™ Handles and the pans are safe for broiler and oven use.

Rating:

