

Saladmaster Multi-Purpose (MP5) Oil Core Automatic Rice Settings



The digital heat control features two convenient automatic rice settings that take all the guess work out of cooking rice. **It?s as easy as 1-2-3!**

1. Insert desired ingredients. (See guide below.)
2. Press the temperature key.
3. Press the down arrow key once to select RIC1 or twice to select RIC2. Display will flash the chosen setting. When flashing stops, heating has begun. The unit will automatically heat to boiling, cook the rice (a countdown timer will appear in the display) and then switch to the keep warm temperature of 150°F (65°C) when cycle is complete.

RIC1 ? Low setting/shorter cooking time used for smaller amounts of rice. (1-3 cups dry measure).

RIC2 ? High setting/longer cooking time used for larger amounts of rice. (4-5 cups dry measure) This unit has a capacity of 5 cups dry measure. **DO NOT EXCEED CAPACITY.**

RICE COOKING GUIDE

RICE

WATER

SETTING

Standard Varieties

1 cup

2 cups

RIC1

2 cups

3 cups

RIC1

3 cups

4 cups

RIC1

4 cups

5 cups

RIC2

5 cups

7 cups

RIC2

Jasmine (For best results, rinse rice twice.)

2 cups

3 1/2 cups

RIC1

Calrose

2 cups

2 3/4 cups

RIC1

These are general guidelines. Results may vary depending on quantity, type and brand of rice selected.

Rating:

Select rating Give Saladmaster Multi-Purpose (MP5) Oil Core Automatic Rice Settings 1/5 Give Saladmaster Multi-Purpose (MP5) Oil Core Automatic Rice Settings 2/5 Give Saladmaster Multi-Purpose (MP5) Oil Core Automatic Rice Settings 3/5 Give Saladmaster Multi-Purpose (MP5) Oil Core Automatic Rice Settings 4/5 Give Saladmaster Multi-Purpose (MP5) Oil Core Automatic Rice Settings 5/5